



www.agxcel.com

where precision meets the soil...

877.218.1981

**PART # 20123 (GXSSTJD1700CCS) FERTILIZER TUBEHOLDER
JOHN DEERE 1700 SERIES MAXEMERGE W/ CENTRAL
COMMODITY HOPPER & JOHN DEERE XP**

(Read Instructions Completely before Beginning Installation)

Installation Steps:

Before you begin, verify the “package contents” to ensure all items are included.

Step #1: It will be necessary to cut a small slit in rubber boot on top of shoe in order for the tubeholder to pass through. When running the $\frac{3}{4}$ " tubing across fold sections of the implement follow these steps:

Step #2: Refer to picture on next page for mounting position. Use existing hole in shoe to mount tubeholder.

Step #3: If using an AgXcel Liquid Fertilizer Manifold it will be necessary to use our $\frac{1}{4}$ " quick connector (part # 262) (photo #1), on top of the tubeholder and the manifold tubing must be slipped into the quick connector before it is inserted into the top of the tubeholder.

Step #4: Allow the manifold tube to extend out the bottom of the fertilizer tubeholder about 1" - 1 $\frac{1}{2}$ ".

Step #5: As a general rule the tubeholder should be mounted so that the bottom tip of the tubeholder is about 2" above the ground, or the edge of the opener.

