



www.agxcel.com

where precision meets the soil...

877.218.1981

WHITE STARTER FERTILIZER PLACEMENT TUBE FOR 6000 SERIES PLANTER PART # 18196 (GXSSTT260WHITE)

(Read Instructions Completely before Beginning Installation)

Installation Steps:

Before you begin, verify the "package contents" to ensure all items are included.

- Step #1: Install plastic tubing (provided) into bottom side (where guard is welded) of stainless steel tube. Leave approximately ¼" to 3/16" of the plastic tubing sticking out of the stainless steel tube. You may need to cut off the plastic tubing at this point, as more than enough plastic tubing is provided.
- Step #2: Remove depth gauge wheels and discs, taking note of shim placement.
- Step #3: Remove factory seed tube guard.
- Step #4: Lift Part # 18196 (GXSSTT260WHITE) up into position on row unit.
- Step #5: Align roll pin holes and install roll pins.
- Step #6: Re-install disc openers, taking care to get the correct shim placement.
- Step #7: Re-install depth gauge wheels.

Pictures of this tube are not available at this time. These tubes are mounted the same way as the Part # GXSSTT260WHITE for the 8000 Series. These pictures can be viewed below.

