



www.agxcel.com

where precision meets the soil...

877.218.1981

WHITE STARTER FERTILIZER PLACEMENT TUBE FOR 8000 SERIES PART # 38182 (GXSSTW6080)

(Read Instructions Completely before Beginning Installation)

Installation Steps:

Before you begin, verify the “package contents” to ensure all items are included.

- Step #1:** Install plastic tubing (provided) into bottom side (where the guard is welded) of stainless steel tube. Leave approximately ¼” to 3/16” of the plastic tubing sticking out of the stainless steel tube. You may need to cut off the plastic tubing at this point, as more than enough plastic tubing is provided.
- Step #2:** Remove depth gauge wheels and discs, taking note of shim placement.
- Step #3:** Remove factory seed tube guard.
- Step #4:** Lift Part# 38182 (GXSSTW6080) up into position on row unit.
- Step #5:** Align roll pin holes and install roll pins.
- Step #6:** Re-install seed tube.
- Step #7:** Re-install disc openers taking care to get the correct shim placement.
- Step #8:** Re-install depth gauge wheels.



AgXcel recommends replacing disc openers when you put fertilizer tubes on.