



www.agxcel.com

where precision meets the soil...

877.218.1981

## WHITE STARTER FERTILIZER PLACEMENT TUBE FOR 9000 SERIES PART # 20328 (GXSSTT290WHITE9000)

(Read Instructions Completely before Beginning Installation)

### **Installation Steps:**

Before you begin, verify the “package contents” to ensure all items are included.

- Step #1:** Install plastic tubing (provided) into bottom side (where the guard is welded) of stainless steel tube. Leave approximately ¼” to 3/16” of the plastic tubing sticking out of the stainless steel tube. You may need to cut off the plastic tubing at this point, as more than enough plastic tubing is provided.
- Step #2:** Remove depth gauge wheels and discs, taking note of shim placement.
- Step #3:** Remove factory seed tube guard.
- Step #4:** Lift Part # 20328 (GXSSTT290WHITE9000) up into position on row unit.
- Step #5:** Align roll pin holes and install roll pins, making sure the tab welded to the side of the fertilizer tube fits snug up against the side of the row unit. (You may need to bend this tab to make sure it fits snug, in case it gets bent in shipping.)
- Step #6:** Re-install disc openers, taking care to get the correct shim placement.
- Step #7:** Re-install depth gauge wheels.

