

# EX 20

Light Treater

## QUICK START GUIDE

-top part  
item **START** refers to the key on the side which allows user to start the procedure ( key).

-central part  
the value is the set filling quantity (in gallons). On the side, the symbol is displayed.

-bottom part  
item **Quantity** refers to the key on the side which allows user to set tank filling value ( key).



1) Press key for 2 seconds to open the manu for setting the filling quantity.



2) Set filling quantity:  
 A) Press to move through digits.  
 B) Press a few more time to edit the highlighted digit.  
 C) Press to save changes, or  
 D) Press to quit the page without comfirming changes.




3) Keep key pressed for 2 seconds. This will start the system. Filling will begin. The system will stop automatically when completed.




The display shows the following data:

- top part: set filling quantity;
- central part: partial totalizer;
- bottom part: instant flowrate.

Press  key several times to view a value in extended mode until required value is displayed in central part.



**Displayed values cannot be edited.**



Tank filling can be interrupted at any time by pressing **ESC**. **Pause** message will be shown at the bottom of the display.

Press **OK** to resume filling; press **ESC** to stop filling and display will go back to initial page.



When set quantity is reached, filling stops automatically. **Completed** message will be shown at the bottom of the display.